


⊕ POSITION TOL TO COORDINATE TOL
 COORDINATE TOL TO ⊕ POSITION TOL

X COORDINATE



EXAMPLE:

ϕ.010 DIA ⊕ POS TOL = ±.0035 COORDINATE TOL

COORDINATE TOTAL TOLERANCE ZONE

⊕ POSITION TOLERANCE ZONE

